



## Quick Reference Guide

1. Disarm – Enter 4 digit code then press “OFF”  
(1 on keypad)
2. Arm to away – Enter 4 digit code then press “AWAY”  
(2 on keypad)
3. Arm to stay – Enter 4 digit code then press “STAY”  
(3 on keypad)
4. Chime on or off: Master code then 9  
(toggles between chime on/off)
5. Bypass zone: Master code – 6 – zone number  
(need to have zero first for single digit zones)
6. Clear error: Master code – 1 (off) same as  
disarming panel

### Who to call at The Sound Vision Security

Monitoring station for false activation:

**248-837-4890**

The Sound Security Office for system service:

**248-804-8011**

User codes

1. \_\_\_\_\_
2. \_\_\_\_\_
3. \_\_\_\_\_
4. \_\_\_\_\_

Mobile App Login

User Name: \_\_\_\_\_

Password: \_\_\_\_\_