



Quick Reference Guide

1. Disarm – Enter 4 digit code then press “OFF”
(1 on keypad)
2. Arm to away – Enter 4 digit code then press “AWAY”
(2 on keypad)
3. Arm to stay – Enter 4 digit code then press “STAY”
(3 on keypad)
4. Chime on or off: Master code then 9
(toggles between chime on/off)
5. Bypass zone: Master code – 6 – zone number
(need to have zero first for single digit zones)
6. Clear error: Master code – 1 (off) same as
disarming panel

Who to call at The Sound Vision Security

Monitoring station for false activation:

248-559-8609

The Sound Security Office for system service:

248-804-8011

User codes

1. _____
2. _____
3. _____
4. _____

Mobile App Login

User Name: _____

Password: _____